INTERLOCKING SCHEME & BREAKER POSITIONS					
CASE	NORMAL OPERATION (BOTH TRANSFORMERS IN SERVICE)				
	A	B	C	D	E
	TR – 1	BC – 1	BC	BC – 2	TR – 2
1	ON	OFF	OFF	OFF	ON
	TRANSFORMER 1 UNDER MAINTENANCE				
2	OFF	OFF	ON	OFF	ON
	TRANSFORMER 2 UNDER MAINTENANCE				
3	ON	OFF	ON	OFF	OFF
	BOTH TRANSFORMER UNDER MAINTENANCE				
4	OFF	ON	OFF	ON	OFF
	GENERAL – 1 (ONLY BC – 1 SIDE I/P)				
5	OFF	ON	ON	OFF	OFF
	GENERAL – 2 (ONLY BC – 2 SIDE I/P)				
6	OFF	OFF	ON	ON	OFF